

1	Fresh air vent	23	Rudder trim indicator
2	Light test & day/night dimmer switch	24	Alternate static source switch
3	Warning lights	25	Storage rack
	Oil pressure low	30	Indicator lighting knob
	Fuel pressure low	31	Avionic master switch
	Fuel low level	32	EDM900
	Low Volt	33	Propeller control
	Starter motor engaged	34	Safety interbreakers (from LH to RH)
	Option		Landing light
	Option		Taxiing light
	Towing Hook		Electric fuel pump control
4	Flaps position indicator lights	35	Electric flaps control lever
5	Magnetic compass	36	Breakers
6	Elevator trim position indicator	37	Bose headset jack (front & rear)
7	ELT remote control	38	Cabin heat/windshield defrost control
8	Instrument panel lighting (from LH to RH)	40	Standard headset jacks
	Light 1: panel lights	41	Battery master switch
	Light 2: Overhead flood lights	42	Alternator relay switch
	Light 3: radio & instruments lights	43	Starter key
9	Safety interbreakers (from LH to RH)	44	Auxiliary tank fuel level
	Navigation light	45	Carburetor heat control
	Strobe light	46	Mixture control
	Pitot heating	47	Throttle control
10	Flight recorder light	50	Elevator trim control
11	Stopwatch	51	Rudder trim control
12	Towing cable release grip	52	Push to talk
13	Avionics breakers	53	Parking brake control knob
20	TCAS mute switch	54	Fuel tank selector
21	TCAS	55	Horameter
22	Gyro horizon	56	Auxiliary 12V socket